

Installation Instruction


ITEM NO:LY7801-02







Spare parts List

5	Screw	10	Top Guide Rail		
4	ST4×30 Truss Head screw	9	Large wheel		
3	Ø6 Plastic expansion glue	8	Anti-jump nails	13	Little handle
2	Guide Block	7	Tube sleeve	12	Handle
1	Bottom Guide Rail	6	bubble rubber bar	11	Moving glass
No.	Description	No.	Description	No.	Description



Measure by spirit level, adjust to make sure the installed position is horizontal.







The Top Guide Rail can be cut from either end.

The Bottom Guide Rail needs to be cut equally from both ends to keep the center guide holes centered.


Cut the Top Guide Rail -D shorter than the top dimension W1.

Cut the Bottom Guide Rail -D shorter than the bottom dimension W2







Lock the left and right side column tightly by a $ST5 \times 30$ tapping screw.





Measure by spirit level, adjust to make sure the installed position is horizontal.






Install the moving glass.





Install the handle.



Apply good quality mildew-resistant silicone to the interior of the shower door along the walls and threshold. It can be used after 24 hours.



Please read this instructions before installation.

Precautions before installation.

- The shower room should be installed by professionals according to instructions. Othervise, the shower room may be unstable or fall down which will lead to product broken or people injured.
- Count the object quantity. The glasses must be moved by two people. Put a soft and non-slip object under the glass and stand the glass against a wall smoothly. It will make the glass borken if it is placed in horizontal position. Pay attention to avoid hitting the four corners of the glass.
- Don't strongly knock the glass to avoid being broken.
- Before instsall the shower room, read the instructions carefully and know well about the tooling and installation sequence.
- It can be used and clean after 24 hour installation.



Maintenance and repair

- 1. Don't let children, older people or activity restricted people go into the shower room alone.
- 2. Don't climb, lean against or hang something heavy on the shower room.
- 3. Don't be rubbed or knocked by hard object, in case to cause broken.
- 4. Don't make the burning cigarette near the shower room, and don't leave cigarette ash in the shower room. The burning flame will destroy the spray and glass, so it must keep away from fire.
- 5. Before entering the shower room, pay attention the height of the falling in order to avoid getting tripped.
- 6. Before entering the shower room, don't put the hand into the crack of the door,in case any injured occur.
- 7. The soap suds in the shower room will make people slip very easily, Be carful not to slip.
- 8. The shower room should be kept in good ventilation, in case to avoild leaving the moisture long stay in the shower room, and cause mildew and bad smell.
- 9. Regularly clean the sliding rail, sliding wheel and sliding lump, add lubricant (lubricant oil or lubricant wax).
- 10. Regularly adjust the screw of sliding wheel, sliding lump to make sure the effective load bearing and good sliding position of the moving door.
- 11. Please use neutral liquid detergent and smooth fabric to clean the shower door. Don't use any acidity, alkaline detergent, thinner, alcohol, acetone and any stronge detergent.
- 12. When dirty water appear on the water retaining stone, you can wipe it with a little toothpaste by wet fabric.
- 13. It will be leaking if the glass seal is dropped. So please make it up when dropped.